





ENGINEERS ONS IN INCHES 6-52- 10 6 4-36 NS (RUSH WASHER ODE REC STAND, ATTACH AT A CORNER COLUMNS. 7.0


ISSUED USE ONLY PO ENLEY-ON-THANES. -1 4001071 ORDER S MOLEG DRILL Nº 38 ADIA 8 MOLES SOUL NO 2 HOLES TAP TOA 0 6 SE DIA 0 0 ZI. 15 DIA 0 2 689. 0 16 C96 AGIA 2 Noves TAD 7 BA 1:0 CRS SHOLES DRILL No 35 ADIA 10.00 h 0 0 35 DIV. 0 0 0 1/A x 28 10 003 0 and A 8 HOLES P. 19538 2 HOLES A DIA DRILL Nº38 TAP 784 C25 10 QIA in, Oi 0 DIA CHE BCB



















ers of ALLEN SET STREW \$ 500 mg All Hop 2 HOLES DRILL NE 40 70,00 \$ 000 32 Age 32 31 BOIN & DIA 2 HOLES DRILL Nº 38 a Dia 2 HOLES DRILL HOBB DRILL NO 38 45 2 HOLES (alterior 43 16 0.85 TAD TBA IG CES 4-36 NS 2 40183 11 - Nº 40 . 2005

















DWG 90016

DWG 90017

CAPCOM HAS THE ORIGINALS AND A COPY OF THIS "PIECE MAP". THESE COPIES ARE PRETTY SAP DUE TO THE SHAPE OF THE ORIGINALS, BUT HE SHOULD BE ABLE TO ANSWER ANY QUESTIONS.

ASSEMBLY INSTRUCTIONS

- 1. The High Pressure cylinder is located at the front of the engine, flywheel at the rear.
- 2. The right-hand side of the engine is that side when viewed from the rear, looking forward.
- Parts that require to be numbered for matching purposes are numbered on the front and/or right-hand side.
- 4. Split bearings (main and cam bearings) must be kept as matched pairs and are so numbered so that they can be matched and reassembled in their original locations. In case the numbers become obliterated, a duplicate numbering by center-punch marks has been made.
- Parts which may be assembled in different locations and/or which may be assembled in more than one rotational position should be assembled in the location and rotational position which gives the freest and best assembly. Trial and error method should be used.
- 6. All studs, bolts, nuts, etc., are "free running". Any tightness on assembly should be treated with caution cross threading should be looked for, i.e. a stud not true to the surface should be backed off and re-fitted perpendicular to the surface. Be cautious of intermix of American Standard and British Association threads.
- 7. All studs and bolts have British Association threads.
- 8. The following carry American Standard threads:-

Piston to piston rod.

Cylinder columns.

H.P. cylinder casting to L.P. casting.

Set screws for eccentrics.

Split eccentric halves.

Valve rod and nut.

Valve rod and head.

Hand wheel (set screw).

Hand wheel guide and nut.

Reversing screw and barrel nut.

Air pump shaft to piston.

Air pump shaft to slide plate and arm.

Air pump valve nut.

Feed pump, shaft to slide plate and arm.

Intermediate valve tail rod guide in cylinder block.

Air pump, inlet and outlet.

Main steam inlet (H.P. valve chest).

Valve reversing shaft levers.

Bottom cover plate, for guide bar screws.

Guide bar bracket, for guide bar screws.

- 9. Special caution 4-40 American Standard threads have been used when substituted for 7 B.A. except 4-36 threads for hand wheel reverse screw guide, also shortened 7 B.A. bolt, top rear pipe flange.
- 10. If this model is to be assembled and disassembled a number of times, it is advisable to assemble all stude finger tight only and all nuts only sufficient to make a secure assembly.
- liake certain that all sub-assemblies with moving parts are completely free of binding before proceeding to next assembly.
- 12. When completing the assembly of the steam engine and making the valve timing and adjustment, be cautious when turning the engine, making certain that the valve does not "Bottom out", causing resistance to turning of the engine. Check in both forward and reverse. Damage may be done to eccentric rods if the engine is turned further until this adjustment is corrected so that the valves will not hit at the end of their travel.

The sliding action that takes place in the Exp. links (Item 30) also during adjustment may reach the limit of its travel - again damage may be caused if this is not adjusted to give clearance at both ends of travel. Drag links, if not properly aligned will allow the valve head bolt to foul the drag links. Any of these occurrences can cause damage and should be treated with suspicion if at any time increased resistance to turning of the engine is felt.

13. Good Luck:

STEAM ENGINE PARTS

BAG No.

Landon

CONTENTS

3 MANIFOLDS

(LONG SCREWS FOR OPEN ENDED MANIFOLD

CYLINDER TOP COVERS

SHEET METAL CYLINDER COVERS AND

SCREWS

MATCHIUG

NO. I AND 2 VALUE RODS (NUMBERES)
FROM OPPOSITE END FROM FLYWHEEL)
EXPANSION LINK
DRAG LINKS

VALUE CHEST AND VALUE (OPPOSITE END
FROM FLYWHEEL)
8-STUDS
2-NUTS

MATCHING EXPANSION LINK

ORAC LINKS

VALUE CHEST AND VALUE (FLYWHEEL END)

8- STUDS

2- NUTS

B HAND WHEEL

9 15 FLYWHEEL

10 REVERSING SHAFT AND LEVERS

MO. B AND 4 VALUE ROOS
EXPANSION LINK
DRAG LINKS

CALINDAL - ELONE OF ENCINE)

MATCHING (HIGH PRESSURE PISTON AND RING

1 apr

AIR PUMP ASSEMBLY

15

FEED PUMP ASSEMBLY

16 10

CONNECTIVE ROD (REAR OR FLYWHEEL END)

17

CENTRE DONNECTING ROO

18

COLUMNS

GUIDE BAR BRACKETS

4 flat heads-base plate

19

CRANKSHAFT

20

SOLEPLATE AND STARIUGS.

21

MATCHING (REAR CYLINDER PISTON (NO RING)

PISTON ROD ASSEMBLY

ROTTOM COVER

22

MATCHING PISTON ROD ASSEMBLY
ROTTOM COVER

23

CENTER VALUE ASSEMBLY

24

HIGH PRESSURE CYLINDER 11-STUDS (TOP AND BOTTOM)

25

39-STUDS (TOWALD BOTTOM)