

9-16-77

Bill -

To use this new transducer, the resistor inside the pressurometer soldered to the connector must be removed. Just clip it out. The smaller tape circles are used to hold the transducer in place. The side with the circular white stay flat goes against the skin. The larger tape overlays go over the transducer once it is positioned if you need them. Call me if you have any questions.

*Dave Squires*  
Dave Squires

DS:rz